

# Cord winder for outdoor roller blinds - dark brown

## Product codes:

Reference: AM8078

EAN13: -

UPC: 39253000

## Product features:

Color: Brown

## Product attributes:



## Product description:

The cord winder for outdoor roller blinds is used for manual control of roller blinds using a cord. It is designed as a spare part for installations with a cord of the corresponding diameter and allows wall mounting.

## Technical specifications

- Product type: cord winder for outdoor roller blinds
- Color: dark brown
- Designed for cords with a diameter of 4 to 4.5 mm
- Dimensions: 166 × 139 × 22 mm
- Design with a mechanical self-winding brake
- Wall mounting

## Functions and features

- Used for winding and guiding the control cord of an outdoor roller blind.
  - The integrated self-winding brake helps to keep the cord in the desired position.
  - The cover in a dark brown design is suitable for mounting in places where color matching with the surroundings is required.
  - The construction is designed for wall mounting using mounting screws.
-

**Ideal for**

- Replacement of a damaged or worn cord winder of an outdoor roller blind.
- Manual control of outdoor roller blinds with a cord of the corresponding diameter.
- Installations where a dark brown winder cover is required.

**Package contents**

- Cord winder for outdoor roller blinds.
- The cord is not included in the package.
- Mounting screws are not included in the package.

**Why choose this product**

- Dimensions and design for cords with a diameter of 4 to 4.5 mm allow use as a spare part in corresponding roller blind assemblies.
- The mechanical self-winding brake ensures the function required for manual control of the roller blind.
- The dark brown design meets the requirement for color-inconspicuous mounting near brown or dark elements.

**Installation and operation instructions**

- Before mounting, verify the diameter of the used cord.
- Fasten the winder to a firm and flat surface with suitable fasteners.
- Use mounting screws corresponding to the wall material, as they are not included in the package.
- After installation, check the free movement of the cord and the correct function of the brake.

**Safety warnings**

- Perform the mounting only when the roller blind is secured to prevent spontaneous movement of the roller blind.
- Do not use the winder with a damaged, frayed, or inappropriately sized cord.
- After mounting, check the firmness of the attachment to the wall.

**Product gallery:**

---

